

TeleNav™ Hardware Installation Guide

TeleNav Phone Mount

Attach the small rectangular metal plate to the back of the battery cover of your phone. Using a mild cleaner like Windex, clean any dirt, or grime from the battery cover. Peel the protective paper from the small rectangular metal plate. Press the metal plate onto the cover at the position shown:



Shape the mount so that it will place the phone conveniently in front of your right shoulder. To reduce sway, rest a bend in the mount on the dash of your car. Peel the protective paper from the back of the mount's suction cup, flip the plastic lever away from the suction cup, place the suction cup against the glass, and then flip the lever toward the glass for maximum suction. Park the phone against the felt covered magnetic area. The i90c, i95cl, and i99cl should ride high on the mount or the magnet will trigger the cover closure sensor and the display will be blanked. Orient the shelf so it is to the right of the lighter phones, and on the bottom of heavier phones.



NOTICE: This mount is not intended to retain the mobile phone, or to adhere to the windshield during rough road conditions or the impact associated with an automobile accident. Recognize these limitations, and use the mount at your own risk.

Mobile Charging Cable

Open the protective plastic insert that conceals the connector at the bottom of the phone. Connect the charging cable to the phone, and connect the other end to your vehicle's cigar lighter socket.